JCB EXTENDED WARRANTY | COVERAGE CHART



| | | | I | | Powertrain | I | Premier | December | | | | |
|---|------------------|---------------------|--|------------------|------------|---|---------|---------------------|---|-----------------------|---------------------|--|
| COVERED COMPONENTS | Premier Cover | Powertrain Cover | COVERED COMPONENTS | Premier Cover | Cover | COVERED COMPONENTS | Cover | Powertrain Cover | COVERED COMPONENTS | Premier Cover | Powertrain Cover | |
| ENGINE | | | TRANSMISSION | | _ | Hydraulic Lines | ~ | × | Brake Master Cylinder | V | × | |
| AC Compressor/Condenser | ~ | × | ABS Sensor | ~ | × | Hydraulic Motors | ~ | × | Brake Pedal & Pedal Assembly | × | × | |
| Air Compressor | V | × | Bearings, Rubber Buffers & Seals | ~ | ~ | Hydraulic Oil Cooler | ~ | × | Control Valves & Brake Lines | v | × | |
| Air Filters & Filter Elements | × | × | Clutch & Clutch Components | ~ | ~ | Hydraulic Oil Filter Base | ~ | × | Parking Brake | v | × | |
| Axle Seals | V | × | Differential Clutch Packs | v . | ~ | Hydraulic Oil Temp Sensor | v . | × | Vacuum Pump & Wheel Cylinder | v | × | |
| Camshaft & Camshaft Bearings | ~ | ~ | Hydrostatic Drive Pumps & Drive Motors | ~ | ~ | Hydraulic Pumps | ~ | × | Wet Brake Assemblies | v | × | |
| Coolant & Water Lines | V | × | Joysticks – Directional Control | v . | ~ | Hydraulic Swivel | v . | × | | | | |
| Crankshaft, Main & Rod Bearings | V | ~ | Kingpins & Bushes | × | × | Hydraulic Tank | v . | × | CAB INTERIOR | | | |
| Cylinder Block & Cylinder Head | V | ~ | PTO | v . | ~ | Hydraulic Valves | v . | × | Circuit Board | v | × | |
| DEF Components | V | × | Torque Converter Group | v . | ~ | Joysticks – Implement & Directional Control | v . | × | Fuse/Circuit Breaker Panel | v | × | |
| DEF Tank | ~ | × | Transfer Case Group | ~ | ~ | Pilot Valve | ~ | × | Heating & Air Conditioning | v | × | |
| Diesel Particulate Filter (DPF) | V | × | Transmission Case/Housing | ~ | ~ | Quick Hitch & Quick Release Couplings | × | × | Gauges/Indicators/Instruments | ✓ | × | |
| Electronic Control Modules (ECM) | V | ~ | Transmission Gears | ~ | ~ | Steering Gear & Valve | ~ | × | Relays/Circuit Breakers | v | × | |
| Emissions Control Components | ~ | ~ | Transmission Hydraulic & Electronic Controls | ~ | ~ | Transmission Oil Lines | ~ | × | Seat | v | × | |
| Engine Oil Filter Base | ~ | ~ | Transmission Oil Cooler | ~ | ~ | | | | Steering Column & Console | V | × | |
| Exhaust Silencer | V | × | Transmission Oil Filter Base | ~ | ~ | STEERING & SUSPENSION | | | Wiring Harnesses/Switches | v . | × | |
| Fan & Fan Drive | V | ~ | Transmission Shafts | V | ~ | Axle Spring | ~ | × | 8 | | | |
| Fan Motor | ~ | ~ | | | | Bogie Suspension | ~ | × | STRUCTURES AND MAINFRAME | | | |
| Flywheel | V | ~ | DRIVE TRAIN | | | Cross Slope Control | V | × | Chassis/Implement Frames | ~ | × | |
| Fuel Injection Pumps & Injectors* | ~ | ~ | Axle Housing | ~ | ~ | Equaliser Bar & Support | ~ | × | Recoil Spring | 1 | × | |
| Fuel Lift Pump | ~ | ~ | Axles & Axle Shaft | ~ | ~ | Equaliser Bar Center Pin Support Stabilizer | 1 | × | Track Roller Frame/Track Adjuster | 1 | × | |
| Fuel Lines | ~ | × | Differential & Final Drive Oil Coolers | ~ | ~ | Power Steering Logic Module | ~ | × | Weldment/Carbody/Main Frame | 1 | × | |
| Fuel Pump/Governor Drive | 1 | ~ | Differential Case/Housing | ~ | ~ | Rubbers & Bushes | × | × | | | | |
| Fuel Tank | ~ | × | Differential Gears | ~ | ~ | Steering Linkage | ~ | × | STARTING /CHARGING | | | |
| Hub Seals | 1 | × | Differential Shafts & Bearings | ~ | ~ | Suspension Control & Control Valve | ~ | × | Alternator | ~ | × | |
| Glow Plugs | × | × | Differential Steering | 1 | 1 | Suspension Cylinder | ~ | × | Battery Cables | | × | |
| Governor/Speed Controls & Linkages | ~ | × | Electric Final Drive Motors | 1 | ~ | Tie Rod | 1 | × | Main Power Relay | | × | |
| Inlet/Exhaust Valves | 1 | ~ | Final Drive Case/Bore | 1 | 1 | | | | Regulator | | × | |
| Intercooler | 1 | ~ | Final Drive Chain/Gears | 1 | ~ | ELECTRONICS | | | Starter Motor | | | |
| Manifolds, Intake & Exhaust | | ~ | Final Drives/Planetary Gears | 1 | ~ | Drive Battery Pack – E-Tech | ~ | ~ | Starter Solenoid Alternator/Generator | | × | |
| Oil Cooler | | ~ | Driveshafts/Universal Joints | 1 | ~ | ECM, ECU** | 1 | 1 | Start Switch | | i i i | |
| Oil Pump & Pan Group | | ~ | Seals, Pipes & Hoses | × | × | GPS When Factory Fitted | | x | Start Switch | • | | |
| Pipes | | × | Steering Clutch | | 2 | Instruments | 2 | x | | | | |
| Piston & Connecting Rod | 1 | ~ | Steering Clutch & Brake Control Valve | 1 | 1 | Lights, LEDs & Batteries | * | x | IF A COMPONENT IS NOT LISTED AS COVERED THEN IT IS NOT CONSIDERED COVERED UND | | | |
| Piston Pins & Rings | | ~ | Swing Gear | | ~ | Radio | | × | | | | |
| Radiator | | × | Universal Joint | 1 | 1 | Relay | × | × | THE JCB WARRANTY PROGRAM. | | | |
| Rocker Arm & Shaft Assembly | | 2 | | | - T | Sensors, Solenoids, Switches | 2 | × | | | | |
| Rush Rod & Balancer | | ~ | STEERING & HYDRAULICS | | | Wiper Motors | ~ | x | COMMONLY EXCLUDED COMPONENTS | FOR ALL CO | VERAGES: | |
| Senders/Solenoids/Sensors | 2 | ~ | Accumulators | ~ | × | Wiper & Wiper Components, Motor & Blades | × | x | | | | |
| Thermostats | | ~ | Drive Train Oil Lines | ~ | â | Wiper & Wiper Components, Plotor & blades Wiring Harnesses | 2 | ÷. | Back up Alarm, Batteries, Boom Wear Pads, Bushes, Cab Floor & Floor Mats, Cab Panels, Cylinder Packing, Doors, Door Latches & Locks, Dozer Blades, Fasteners, Fenders, Filters, Gas Struts, Glass, Ground Engaging Wearparts, Handles, Hinges, Horn, Lights, Mirror, Mirror Brackets, Mud Guards, Operating Fluids, Pins, Roof & Roof Lining, Seals, Seat Fabrics & Cushions, Seatbelt, Straps, Tyres, Tool, Washers, Windows, Wiper Blades. | | | |
| Timing/Accessory Gears | ~ | ~ | Electronic Controls – Implement & Steering | ~ | â | wing hamesses | ~ | • | | | | |
| Timing/Accessory Gears Timing Chain/Belt | ~ | ~ | Ground Driven Steering Pump | ~ | x | BRAKE SYSTEM | | | | | | |
| • | | ~ | 0 1 | ~ | x | | ~ | × | | | | |
| Turbocharger | | ~ | Hydraulic Accumulators | | | Accumulator | | × | | | | |
| Valve Cover & Base/Valve Spring & Guide | ~ | ~ | Hydraulic Cylinders Hydraulic Hoses | ~ | ×× | Brake Caliper Brake Fluid | × | × | *Multiple Fuel Injectors occurring at the same time **Related to Powertrain components only on PT cover | | | |
| Water Pump/Thermostat | v | × | I IYUI AUIIC FIUSES | | • | | • | • | | | | |